




The polygraph

Instructions for use (with CPAP)

01

Step 1: confirm device

- Attach the device on top of your pyjamas.
- Place the device **in the centre** of your chest using the strap. The strap should be **under** the armpit.
- **If you have a cardiac pacemaker, wear the straps reversed. The device will then be at the level of the navel and the abdominal belt under the armpit.**



02

Step 2: attach the abdominal belt

- Attach the belt at the height of the navel.



03

Step 3: attach the intermediate piece



- Attach the intermediate piece between your tube and the CPAP-mask. A rubber tube runs from the intermediate piece to the device.



04

Step 4: place finger sensor

- Place the finger sensor on your **left** ring, middle or index finger so that the fingertip remains inside the rubber part. The cable runs along the top of your hand. Attach a piece of adhesive tape to your finger/arm.



You are now ready to go to sleep!



Questions?

If you still have questions after reading this brochure, do not hesitate to ask. The nurses at the sleep laboratory will be happy to help you.

sleep laboratory
tel.: 011 69 97 18



Diestersteenweg 100 • 3800 Sint-Truiden

www.sint-trudo.be

Follow us on   